

Install Keil MDK Version 5

- Download and install the MDK Core from www.keil.com/mdk5/install

Add Software Pack using the Pack Installer

- **Keil::STM32F1xx_DFP** – STMicroelectronics STM32F1 Series Device Support

Power up the board

- Connect a USB power supply to the **Power** receptacle
- Connect the board to the PC using the **Trace Connector** and a debug adapter, for example ULINKpro

Verify Installation using example projects provided in the Software Pack

- Copy an example using the Pack Installer. Compile, download to Flash, and debug the application. The provided examples are ready to run. Trace settings might have to be adapted.

More Information



- Evaluation Board Description www.keil.com/boards2/keil/mcbstm32e
- MCBSTM32E User's Guide www.keil.com/support/man/docs/mcbstm32e

Related Information

- MDK Version 5 www.keil.com/mdk5
- MDK-Professional Middleware www.keil.com/mdk5/middleware
- Learning Platform www.keil.com/mdk5/learn

ULINKpro Debug and Trace Adapter

Connect ULINKpro to the board's **Trace** connector and choose **ULINK Pro Cortex Debugger**.




Click **Settings** and configure the **Debug** connection for Serial Wire Debug (SWD) by selecting the Port **SW**.

Trace Settings

Configure trace by selecting the **Trace** tab and enter the correct CPU **Core Clock** speed as specified in your project. Check the **Trace Enable** box.

For complete instruction trace, select **Sync Trace Port with 4-bit data** and enable **ETM Trace Enable**.



More Information

- Getting Started User's Guide

www.keil.com/gsg